

## Bolts/Belay stations or other, all in one No re-drilling

- Measuring stick method
- 24cm between center's seems to be perfect for Raumer belay stations
- This distance will vary according to different manufacturers of belay stations.
- This allows for any configuration of bolt combinations - 2 x ring hangers, 1 x hanger 1 x ring hanger or if the canyon is a classic add a belay station. Screw ins would also work for first descents, then either add expansion bolts or glue could be used with any combination you like.
- Find a piece of wood (or other material) cedar is best because it doesn't bend when wet. Mark 24cm between centres. Drill pilot holes. Drill 10/12mmmm holes.
- Drill first hole in rock - use your measuring stick to drill the second hole in the right place at the correct angle( see manufacturers specs)
- Fit Anchor and GO!

Marking between centres



Drilling



Raumer Belay station

